

BRACKET TO SECURE TOP RAIL TO COLUMN SURROUND. USE 1/4" TAPCON INTO TOP RAIL AND METAL SCREWS INTO COLUMN. PARTS BY OTHERS. SS OR GALVANIZED HARDWARE SUGGESTED.

USE CONSTRUCTION ADHESIVE AT ALL JOINTS

USE CONSTRUCTION ADHESIVE AT ALL JOINTS

1/4" X 3" ALL THREAD DOWEL (FIELD DRILLED) IN 3/8" HOLE. SECURE W/CONSTRUCTION ADHESIVE OR EPOXY

USE FOUR (4) DOWELS PER BASE RAIL SECTION

ALL VIEWS IN SECTION

PROJECT:

TITLE: BALUSTRADE ASSEMBLY

REVISIONS:

TYPE DWG: SETTING PLAN

DRAWN BY:



**Stromberg Architectural Products**  
 P.O. Box 8036, I-30 West, Greenville, TX 75404 (903) 454-8682 FAX (903) 454-3642



SCALE: 3" = 1'

DATE:

DWG. SHEET:

SP.-.-.S.4.R0